

CONTROL ACCESSORIES

RADIO TECHNOLOGY SOMFY® (RTS)



TELIS COLLECTION



Telis 1 RTS Lounge
Single Channel Remote
1810650



Telis 4 RTS Lounge
Five Channel Remote
1810652



Telis 1 RTS Silver
Single Channel Remote
1810639



Telis 4 RTS Silver
Five Channel Remote
1810641



Telis 1 RTS Pure
Single Channel Remote
1810632



Telis 4 RTS Pure
Five Channel Remote
1810633



Telis 1 Soliris
RTS Pure
1810635



Telis 1 RTS Patio
Single Channel Remote
1810643



Telis 4 RTS Patio
Five Channel Remote
1810645



Telis 1 Soliris
RTS Patio
1810647



Telis 4 Soliris
RTS Patio
1811243



Telis 1 Modulis RTS
Lounge with
Scroll Wheel
1810976*



Telis 4 Modulis RTS
Lounge with
Scroll Wheel
1810664*



Telis 1 Modulis RTS
Silver with
Scroll Wheel
1810975*



Telis 4 Modulis RTS
Silver with
Scroll Wheel
1810663*



Telis 1 Modulis RTS
Pure with
Scroll Wheel
1811234



Telis 4 Modulis RTS
Pure with
Scroll Wheel
1811235



Telis 16 Channel RTS
Pure Remotes w/
On-screen display
1811020



Telis 16 Channel RTS
Silver Remotes w/
On-screen display
1811021



DECOFLEX WIREFREE™ WALL SWITCHES & TABLE TOP ACCESSORIES



DecoFlex 1
Channel RTS
Wireless Wall Switch



DecoFlex 2
Channel RTS
Wireless Wall Switch



DecoFlex 3
Channel RTS
Wireless Wall Switch



DecoFlex 4
Channel RTS
Wireless Wall Switch



DecoFlex 5
Channel RTS
Wireless Wall Switch



DecoFlex Tabletop RTS
Accessory Black
1811051**



DecoFlex Tabletop RTS
Accessory Silver
1810972**



DecoFlex Tabletop RTS
Accessory White
1811185**

Wall Switches shown in white. Also available in black, ivory, and almond finishes. Shown above assembled with printed channel buttons.



**DecoFlex Switch sold separately from Table Top Accessory